



## RECOMMENDED PROCEDURES

### EACH FREEZER BARREL REQUIRES:

**CLEANING:** One 2 oz. Scoop or One 2 oz. Packet of Stera-Sheen Green Label mixed with 2 gallons of water.

**SANITIZING:** One 2 oz. Scoop or One 2 oz. Packet of Stera-Sheen Green Label mixed with 2 gallons of water.

### CLEANING AND DISASSEMBLY INSTRUCTIONS:

1. Follow manufacturer's directions to drain and rinse hopper (or dispenser) and freezing cylinder. Rinse until water is clear.
2. Dissolve one 2 oz. scoop or 2 oz. packet into 2 gallons of warm water. Pour into hopper/dispenser.
3. Agitate solution per manufacturer's suggested wash cycle. Or, manually brush clean making sure solution makes contact with all surfaces.
4. Drain solution completely.
5. Follow manufacturer's directions, take all removable parts to sink. Clean by soaking for at least one minute using one 2 oz. packet per 2 gallons. Allow to air dry. Follow local health ordinances.
6. Repeat procedures for each freezing cylinder or dispenser. To ensure adequate cleaning, do not reuse the solution.

### ASSEMBLY AND SANITIZING INSTRUCTIONS:

1. Assemble machine and lubricate all parts according to manufacturer's specifications.
2. Dissolve one 2 oz. packet in 2 gallons of warm water. Pour into hopper (or dispenser).
3. Agitate sanitizing solution per manufacturer's suggested wash cycle, but for a minimum of one minute.
4. Drain solution completely. Repeat procedures for each freezing cylinder. **DO NOT REUSE SOLUTION. DO NOT RINSE. FOLLOW LOCAL HEALTH CODES.**

\*\*\*Please Note:

-Solutions should NOT be reused for additional equipment.

-Each freezer barrel requires a total of four ounces per process. If solutions are reused, then it will allow an opportunity to compromise food safety.



**A surface must be completely cleaned before it can be properly sanitized.  
A machine that is 90% clean is still 10% dirty.**

